

## 6.9 電線包装用木製ドラム (JCS 8077 : 2013)

表 一般用木製ドラム寸法表

記号及び ドラム番号	つば径 D mm	胴径 d mm	外幅 W <sub>1</sub> mm	内幅 W <sub>2</sub> mm	軸穴径 h mm	巻始口		つば板 a		参考 最大巻込 質量 kg
						幅 H mm	長さ L mm	厚さ mm	構成 mm×枚	
L1 - 2 3 4	370	200	300	240	50	20	110	30	15×2	500
	400									
	430									
L2 - 1 2 3 4 5	430	250	300	240	50	20	140	30	15×2	500
	460									
	490									
	520									
	550									
L3 - 1 2 3 4 5	520	300	400	328	50	25	140	36	18×2	750
	550									
	580									
	610									
	640									
L4 - 1 2 3 4 5 6 7	610	350	400	328	50	30	170	36	18×2	750
	640									
	670									
	700									
	730									
	760									
	790									
L5 - 1 2 3 4 5 6	670	400	500	428	75	35	170	36	18×2	750
	700									
	730									
	760									
	790									
	820									
L6 - 1 2 3 4 5 6	820	450	500	428	75	40	220	36	18×2	750
	850									
	880									
	910									
	940									
	970									
L7 - 1 2 3 4 5	910	500	600	528	75	45	220	36	18×2	750
	940									
	970									
	1,000									
	1,050									
L8 - 1 2 3 4 5 6	940	600	600	528	75	50	280	36	18×2	750
	970									
	1,000									
	1,050									
	1,100									
	1,150									
L9 - 1 2 3 4 5 6 7 8	1,100	600				50	280			
	1,150									
	1,200									
	1,150									
	1,200	700	750	654	110	60	300	48	24×2	1,500
	1,250									
	1,300									
	1,350									
L10 - 1 2 3 4 5 6	1,250	800	750	654	110	70	330	48	24×2	1,500
	1,300									
	1,350									
	1,400									
	1,450									
	1,500									

