

■電線包装用木製ドラム（JCS 8077：2019）

表 一般用木製ドラム寸法表

記号及び ドラム番号	つば径 D mm	胴径 d mm	外幅 W ₁ mm	内幅 W ₂ mm	軸穴径 h mm	巻始め口		つば板 a		参考							
						幅 H mm	長さ L mm	厚さ mm	構成 mm × 枚	概算質量		最大巻込 質量 kg					
										小割 板無 kg	小割 板付 kg						
L2 — 1 2 3 4 5	430	250	300	240	50	20	140	30	15 × 2	6	14	500					
	460									7	15						
	490									8	17						
	520									9	19						
	550									9	19						
L3 — 1 2 3 4 5	520	300	400	328	50	25	140	36	18 × 2	11	21	750					
	550									12	22						
	580									13	24						
	610									14	25						
	640									15	27						
L4 — 1 2 3 4 5 6 7	610	350	400	328	50	30	170	36	18 × 2	14	25	750					
	640									15	27						
	670									16	28						
	700									17	30						
	730									19	32						
	760									20	34						
	790									21	35						
L5 — 1 2 3 4 5 6	670	400	500	428	75	35	170	36	18 × 2	18	33	750					
	700									19	35						
	730									20	37						
	760									21	38						
	790									23	41						
	820									24	42						
L6 — 1 2 3 4 5 6	820	450	500	428	75	40	220	36	18 × 2	25	43	750					
	850									26	45						
	880									28	48						
	910									29	49						
	940									31	52						
	970									32	54						
L7 — 1 2 3 4 5	910	500	600	528	75	45	220	36	18 × 2	31	62	750					
	940									32	64						
	970									34	67						
	1,000									36	70						
	1,050									39	74						
L8 — 1 2 3 4 5 6	940	600	600	528	75	50	280	36	18 × 2	34	66	750					
	970									35	68						
	1,000									37	71						
	1,050									40	75						
	1,100									43	80						
	1,150									46	85						
L9 — 1 2 3 4 5 6 7 8	1,100	600	750	654	110	50	280	48	24 × 2	63	119	1,500					
	1,150									68	126						
	1,200									72	133						
	1,150	700				60	300			70	128						
	1,200									75	136						
	1,250									79	142						
	1,300									84	150						
	1,350									89	157						
L10 — 1 2 3 4 5 6	1,250	800	750	654	110	70	330	48	24 × 2	83	146	1,500					
	1,300									88	154						
	1,350									93	161						
	1,400									98	169						
	1,450									103	176						
	1,500									109	185						

記号及び ドラム番号	つば径 D mm	胴径 d mm	外幅 W ₁ mm	内幅 W ₂ mm	軸穴径 h mm	巻始め口		つば板 a		参考		
						幅 H mm	長さ L mm	厚さ mm	構成 mm × 枚	概算質量		最大巻込 質量 kg
										小割 板無 kg	小割 板付 kg	
L11 - 1 2 3 4 5	1,400	800	900	780	110	70	360	60	30 × 2	128	213	2,000
	1,450									134	222	
	1,500									141	232	
	1,550									149	243	
	1,600									156	253	
L12 - 1 2 3 4 5	1,400	900	900	780	110	80	400	60	30 × 2	132	217	2,000
	1,450									139	227	
	1,500									146	237	
	1,550									153	247	
	1,600									161	258	
L13 - 1 2 3 4 5 6 7	1,500	1,000	900	780	110	85	430	60	30 × 2	150	241	2,000
	1,550									158	252	
	1,600									165	262	
	1,650									173	273	
	1,700									181	284	
	1,750									189	295	
	1,800									197	306	
L14 - 1 2 3 4 5 6 7	1,700	1,200	1,050	906	110	100	530	72	24 × 3	245	385	3,000
	1,750									255	399	
	1,800									265	413	
	1,850									276	428	
	1,900									287	443	
	1,950									298	458	
	2,000									309	473	
L15 - 1 2 3 4	1,900	1,400	1,050	906	110	120	660	72	24 × 3	300	456	3,000
	1,950									311	471	
	2,000									322	486	
	2,100									346	518	
L16 - 1 2 3 4	2,000	1,400	1,200	1,056	110	120	660	72	24 × 3	335	550	3,000
	2,100									359	585	
	2,200									383	619	
	2,300									410	657	
L17 - 1 2 3 4 5 6	2,100	1,600	1,200	1,056	110	130	700	72	24 × 3	373	599	3,000
	2,200									397	633	
	2,300									424	671	
	2,400									451	708	
	2,500									479	747	
	2,600									509	788	

図 一般用木製ドラム構造図の一例

